



TELL US ABOUT DISTRESSED VENEER FROM DECOWOOD:

The veneer market keeps on self-exploring, compelling the companies to launch new trends and innovations. Trailing on the same lines, Decowood unveils its spectacular new range called, 'Distressed Veneer'. This collection retains the beautiful imperfections, accentuating the woods natural beauty with the use of ADT technology. The collection comprises of six extravagant veneers introduced under the name- Distressed - hailing from the Oak, Walnut, Knotty Oak, Knotty Pine, Oak Parquet and Teak trees. Raw textures are versatile and look attractive; the old yet new look of 'distressed' comes in its finest worn out look. With its rustic and rugged, yet sophisticated character, it also incorporates the feeling of outdoor right in the comforts of home.

NEW APPLICATION IDEAS:

Veneers symbolize class and luxury like nothing else. Veneers in conjunction with other materials, make truly exquisite decorations in any woodworking projects. Veneers can be used on walls, flooring and ceiling. Other uses of veneer include furniture from tables to chairs or the interiors of automobiles or boats, as well as decorative designs on musical instruments and more...

THE PROCESS OF VENEER-POLISHING:

Matt Finish

STEP 1: Cutting/Smoothing of wood using Sandpaper to soften edges and Sides.

STEP 2: Use Stains to give color to the wood. Stains are applied in the direction of the veins of the wood. If the veins are vertical, then stain should be applied vertically

STEP 3: Apply Epoxy. Epoxy is durable and resists normal wear, Takes less time to dry.

Note: Less quantity of epoxy is applied to avoid air bubbles. If the dry time exceeds by 3 hours, Sanding is done again and apply a coat of Epoxy again.

STEP 4: Apply BASE COAT (SEALER). Sealer has excellent sheen retention, it is less yellowing. It is Scratch, stain and heart resistant.

STEP 5: Apply TOP COAT MATT Finish.

Gloss Finish

STEP 1: Repeat from STEP 1-STEP 4 of Matte finish

STEP 2: Apply TOP COAT Gloss Finish



PARUL MITTAL
Director – Design & Marketing
Greenlam Industries Ltd.

With its rustic and rugged, yet sophisticated character, Distressed Veneer incorporates the feeling of outdoor right in the comforts of home



APPLICATION OF WOOD VENEERS WITHOUT HASSLES!

Below mentioned points to be taken into consideration before installation of veneers:

- ❖ Both surfaces should be clean and free from dust
- ❖ Adhesive used should be of superior quality – Preferably contact cement
- ❖ Proper time should be given to adhesive to dry down, else it will cause blisters. The time can vary depending on ambient moisture, airflow and temperature
- ❖ Adequate pressure also need to be applied in bonding of two surfaces. Wood Scrapper or Vacuum press is good for bonding. Please do not use J roller
- ❖ Need to wait at least for 4-6 hours before applying any sealers or finishes

Note: Sheets should be installed in accordance with manufacturer's instructions